



Mixing guide for bonsilage products

1



Step 1

Fill the bucket:

- Fill the bucket with clean, cold (10-20°C), non-chlorinated water.
- If using a 100 g or 200 g bottle of **bonsilage**, fill the bucket with 2,5 liters of water per bottle applied.

2



Step 2

Pour the bottle of **bonsilage** product into the mixing bucket.

3



Step 3

Dissolve the **bonsilage** product uniformly in the bucket, you can use the help of a mixer, a stirring tool that you have at your disposal or beat it vigorously if your container has a lid.

Tip: Avoid spillage. If using an electric mixer, work only at low or medium speed.

4



Step 4

Transfer the prepared **bonsilage** product into the dosing tank and, if necessary, add more water (see instructions of dosing system of the machine).

Tip: For a clean filling of the dispenser use a funnel and a strainer.

4A



NOTE:

When mixing **bonsilage in the mixing container, be sure to bring it immediately with the amount of water to the desired concentration and then transfer it to the dispenser.**